



MOUNTING GUIDE

FOR THE

KD135GX-LPU~KD215GX-LPU

SOLAR PHOTOVOLTAIC POWER MODULES

Please read this guide carefully before installing the modules.

Draft 2009.10.12

KD series modules may be attached to a support structure by the following methods. Detailed mounting method is described in 'mounting table'.

For optimal performance in all applications, clearance between the module frame and the mounting surface is required to allow cooler ambient air to circulate around the back of the module and to avoid the module and / or wiring damage.

The minimum spacing of .6" (15 mm) is required between PV module and the mounting surface around the perimeter of PV module. There should also be a clearance of at least .13" (3.2 mm) between the individual modules to allow heat-related expansion.

BOLTING: Utilizing 5/16" or 8 mm stainless steel hardware through the existing .35" (9 mm) diameter mounting holes in the module frame and then through module mounting holes on the support structure. Tighten the screws with adequate torque (132 in-lb).

Refer to the Module Drawings for the position of the solar module mounting holes.

CLAMPING: Fasten modules firmly with clamps using torque values specified by structure manufacturers. Top-down clamps must have a minimum 40mm clamping width, and minimum 9mm overlap onto module frame. Clamps also must not shade the sunlight incidence on glass surface. Clamp material must be either stainless steel or anodized aluminum.

<KD205GX-LPU, KD210GX-LPU, KD215GX-LPU >

Mounting table - 1

	Long Side		Short Side	
Bolting				
Top Down Clamp	<p style="font-size: small;">100mm 100mm 100mm 100mm</p>			
	<p style="font-size: small;">100mm 200mm</p>			
	<p style="font-size: small;">200mm 100mm</p>			
Continuous Clamp				

:
Permissible
clamping range

:
continuous clamp

<KD185GX-LPU>

Mounting table - 2

	Long Side		Short Side	
Bolting	<p>Diagram showing a rectangular panel with four bolt holes. The distance between the left bolt holes is 256.5mm, and the distance between the right bolt holes is 825mm.</p>	<p>Diagram showing a rectangular panel with four bolt holes. The distance between the top bolt holes is 256.5mm, and the distance between the bottom bolt holes is 825mm.</p>		
Top Down Clamp : Permissible clamping range	<p>Diagram showing a rectangular panel with four hatched clamping points. The distance between the left clamping points is 256.5mm, and the distance between the right clamping points is 825mm. The distance between the top clamping points is 100mm, and the distance between the bottom clamping points is 100mm.</p>	<p>Diagram showing a rectangular panel with four hatched clamping points. The distance between the top clamping points is 100mm, and the distance between the bottom clamping points is 100mm. The distance between the left clamping points is 256.5mm, and the distance between the right clamping points is 825mm.</p>		
	<p>Diagram showing a rectangular panel with four hatched clamping points. The distance between the left clamping points is 256.5mm, and the distance between the right clamping points is 825mm. The distance between the top clamping points is 200mm, and the distance between the bottom clamping points is 200mm.</p>	<p>Diagram showing a rectangular panel with four hatched clamping points. The distance between the top clamping points is 200mm, and the distance between the bottom clamping points is 200mm. The distance between the left clamping points is 256.5mm, and the distance between the right clamping points is 825mm.</p>	<p>Diagram showing a rectangular panel with four hatched clamping points. The distance between the left clamping points is 150mm, and the distance between the right clamping points is 150mm. The distance between the top clamping points is 150mm, and the distance between the bottom clamping points is 150mm.</p>	<p>Diagram showing a rectangular panel with four hatched clamping points. The distance between the top clamping points is 150mm, and the distance between the bottom clamping points is 150mm. The distance between the left clamping points is 150mm, and the distance between the right clamping points is 150mm.</p>
	<p>Diagram showing a rectangular panel with four hatched clamping points. The distance between the left clamping points is 256.5mm, and the distance between the right clamping points is 825mm. The distance between the top clamping points is 200mm, and the distance between the bottom clamping points is 200mm.</p>	<p>Diagram showing a rectangular panel with four hatched clamping points. The distance between the top clamping points is 200mm, and the distance between the bottom clamping points is 200mm. The distance between the left clamping points is 256.5mm, and the distance between the right clamping points is 825mm.</p>		
Continuous Clamp : continuous clamp	<p>Diagram showing a rectangular panel with a continuous clamp along the bottom edge.</p>	<p>Diagram showing a rectangular panel with a continuous clamp along the right edge.</p>	<p>Diagram showing a rectangular panel with a continuous clamp along the top edge.</p>	<p>Diagram showing a rectangular panel with a continuous clamp along the left edge.</p>

<KD135GX-LPU>

Mounting table - 3

	Long Side		Short Side	
Bolting				
Top Down Clamp ▨ : Permissible clamping range				
Continuous Clamp ▨▨▨▨ : continuous clamp				